
## Special tool

Vaccum tester




116 589 25 21 00

## Conventional tool


Revolution counter

## **Testing EGR**

1 Pull vacuum line from EGR valve (60), plug-on test hose and activate with vacuum. If operation of engine is not getting clearly worse, replace EGR valve.




2 Check activation of EGR valve. Pull off vacuum line at EGR valve (60) and connect to vacuum tester. Increase engine speed slowly to approx. 3000 rpm. There should be no vacuum up to approx. 1800 rpm. Vacuum connections on throttle valve housing may be mixed up.




a To thermovalve for EGRb To ignition distributor

3 Check thermovalve (37) 50 °C. Pull vacuum line white/brown/purple from EGR valve and activate with vacuum. At coolant temperatures < 50 °C no passage on thermovalve.




## Function diagram EGR



- Mixture controller Intake manifold Exhaust manifold 1 12 31

- Thermovalve 50 °C EGR valve To ignition distributor

Color code br = brown rs = pink rt = red ws = white



Installation: September 1981

Model	Engine	Engine end No. manual transmission	au tomatic transmission	Chassis end No. Installation mixed	Installation continuous
107.042	110.990			010107-011567	011569
123.007 123.033 123.053 123.093	110.988	start of series		085174-096468 024129-024416 010064-010252	096496 024417 010253
126.022 126.023	110.989			021381-043198 039922-042786	043199 042787